

# Assembly Guide for senseBox:bike



# Welcome to the senseBox:bike assembly guide!


This guide shows you how to set up and use your senseBox:bike to collect data while riding your bike.

If you have any questions or need support, feel free to contact us at kontakt@reedu.de

We wish you many enjoyable rides with your senseBox:bike!

# **Component list**

- 1. Enclosure: bottom, lid, frame, as well as small additional components and screws;
- 2. Mount for the seat post;
- 3. senseBox microcontroller (MCU S2);
- 4. Battery with battery board (including cable);
- 5. Time of Flight (ToF) sensor VL53L8CX;
- 6. Fan with integrated cable;
- 7. Temperature and humidity sensor HDC1080;
- 8. Particulate matter sensor SPS30;
- 9. Bluetooth Bee:
- 10. OLED display;
- 11. Adapter board for Sensirion SPS30;
- 12. 3x QWIIC cables;
- 13. 1x particulate matter sensor cable.





### Mount the battery board

Attach the battery board to the base of the housing using two screws. Then insert the battery (note: pay attention to the positive and negative terminals) and connect the battery board with the corresponding cable. Also make sure that the battery board is switched on by ensuring the switch is set to "On."





#### Insert and connect the ToF sensor

Insert the ToF sensor into the designated additional component so that the black cap of the sensor fits exactly into the corresponding cutout and the label (VLC) is positioned at the top of the sensor. Now connect a long QWIIC cable to the left port and a short QWIIC cable to the right port of the sensor






#### Insert the ToF sensor

Insert the ToF sensor into the frame of the housing.
Also insert the other additional components into the designated cutouts of the frame.

#### Connector slot







# Additional components





# **Attach the bottom part**

Using four long screws, fasten the base to the frame.







#### **Insert fan**

Insert the fan into the designated additional component (filter).









#### Insert fan with filter into the enclosure

Then place the set (fan + filter), into the housing. Make sure that the cable runs along the top left and that the label on the fan faces inward.





# **Connect and position the sensor**

Now connect the temperature and humidity sensor with two QWIIC cables and slide it in front of the fan.


Connect the lower cable to the QWIIC port on the battery board.





# Insert and fasten the MCU S2

Place the MCU S2 into the housing as shown and secure it with three short screws.






#### Connect the sensor cables to the MCU S2

Now connect the cables to the MCU S2: Fan - GPIO A

ToF sensor (short cable) - I2C
Battery - Battery (neben On/ Off)






#### **Insert Bluetooth Bee**

Plug the Bluetooth Bee into the designated XBEE slot on the MCU S2.









# **Prepare and mount OLED display**

Remove the protective film from the OLED display, connect a **short QWIIC cable** to the left side, and then fasten the display to the lid with two short screws.








# Insert and connect the adapter board


First, connect the adapter board of the particulate matter sensor to the OLED display using the QWIIC cable, then insert it into the lid.





#### Insert and protect the PM sensor

Place the particulate matter sensor into the lid and connect the cable to the adapter board. Also apply two strips of insulating tape to the sensor as shown, to protect it from the pins of the Bluetooth Bee.





#### **Fasten the PM sensor**

Now secure the particulate matter sensor using the small black plate and fasten it with screws.







# Mount the switch extension

Place the T-shaped additional component over the On/Off switch of the MCU S2 and secure it internally with the U-shaped component.





#### **Final connection and test**

Connect the long cable of the ToF sensor to the OLED display and test whether the MCU S2 can be switched on and off from the outside using the switch.

Note: To make it easier to connect the long ToF cable, you may need to detach the OLED display temporarily from the LID.













#### Transfer the program code

 $You've \ now \ completed \ assembling \ your \ sense Box: bike. \ The \ next \ step \ is \ to \ upload \ the \ program \ code.$ 

- a. Establish connection

  Connect the senseBox:bike to your laptop using a USB-C cable and switch on the MCU S2.
- $\label{eq:b.power} b. \ Open \ removable \ drive \\ A \ removable \ drive \ named \ "senseBox" \ will \ now \ appear \ on \ your \ computer.$
- c. Download the program code

  Download the following program code: 
  snsbx.de/bike
- d. Transfer the program code
  Transfer (copy) the code to the senseBox via drag and drop.
- e. Verify the transfer
  If the RGB LED lights up green, the program code has been transferred successfully.
- f. Further information

  For more information about data collection with the senseBox:bike and the app, please refer to the document "Installation Guide senseBox:bike."



